


## Connection/ Wiring Diagrams

### Part Winding Start (Wye Only)

Speed: Single  
Phase: 3  
Voltage: Single  
Winding: Y only  
Special Feature: Part winding start

**Note:** Suitable for unit previously approved for part winding start (a standard Star - Y 230/460 9 lead motor may often be used for 230V part winding - a special winding is required for 460V part winding start)



[Home](#) [Email](#)

Copyright © 2000 U.S. Electrical Motors, All rights reserved